



CHARACTERISTICS

- Neutral oxime curing, 1-component silicone sealant (RTV-1)
- Very easy to apply
- Very good adhesion to many building materials
- Permanent elasticity
- High resistance to ageing, weather conditions, low and high temperatures
- Meets the requirements of FDA code 21 §177.2600 (e) for food contact.
- MEKO-free
- Mould resistant

APPLICATIONS

- For all types of sanitary applications and rooms with high humidity such as bathrooms, showers, kitchens and cold storage cells.
- Suitable for sealing glazing joints.
- Has an adhesive strength on many materials used in building and engineering industries such as treated wood, aluminium, abs, (stainless) steel, hard PVC, glass, ceramic tiles, armed polyester, hard polystyrene, etc.

TECHNICAL CHARACTERISTICS	
Uncured sealant	
Type of sealant	Polysiloxanes
Curing system	Through moisture in the air
Skin forming time (23°C and 50% R.H.)	10 - 15 min.
Curing rate (23°C and 50% R.H.)	2,5 - 3 mm after 24h
Density: ISO 1183	1,22 g/ml (Sanitair N) 1,01 g/ml (Sanitair N T)
Processing temperature	+5°C - +40°C
Shelf life, in the original packing in dry conditions between +5°C - +25°C	15 months
Cured sealant	
Shore A hardness: ISO 868	23 (Sanitair N) 13 (Sanitair N T)
Elastic recovery: ISO 7389	> 90%
Deformation capability: ISO 11600	25%
Modulus at 100% elongation: ISO 8339	0,35 N/mm ² (Sanitair N) 0,25 N/mm ² (Sanitair N T)
% Elongation at break: ISO 8339	300% (Sanitair N) 200% (Sanitair N T)
Temperature resistance	-50°C - +150°C

PACKING AND COLOURS
Other colours are available on request (75 cartridges or multiples).
12 cartridges of 300 ml/box - 100 boxes/pallet
25 cartridges of 300 ml/box - 48 boxes/pallet
Sanitair (colour): white, light manhattan
Sanitair T (transparent base): transparent, transparent/grey

METHOD OF USE

Preparation

All surfaces should be dry, clean and free from dust or grease. When necessary, degrease with **Parasilico Cleaner**, MEK, alcohol or ethanol. If necessary, use a primer. It is recommended to carry out preliminary tests in order to determine the suit-

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply.

ability of the product for its application.

Primers

Porous surfaces	Silicone Primer Porous Surfaces	Transparent	Drying time (approx.) 60 min.
Non porous surfaces	Silicone Primer Non-porous Surfaces	Transparent	Drying time (approx.) 60 min.

Application

- With a sealant gun (manual or pneumatic). The size and shape of the joint is very important. Avoid thin joints.
- Use in well-ventilated rooms. Good ventilation is important during application and curing of the product.
- Do not subject the joint to thermal, mechanical or chemical stress before curing is complete.

Joint dimensions (Maximum joint width: 30 mm)

Joint width	Joint depth	Allowed difference
3-4 mm	3-4 mm	± 1 mm
6 mm	6 mm	± 1 mm
8 mm	8 mm	± 1 mm
10 mm	6-8 mm	± 2 mm
15 mm	10 mm	± 2 mm
20 mm	10-12 mm	± 2 mm
25 mm	15 mm	± 3 mm
30 mm	18 mm	± 3 mm

Tooling

If desired, smooth surface before skin formation with the **Perfect Joint Tooling Agent** and/or the **Perfect Joint Tool**. Avoid that tooling agent ends up on the surface before applying the silicone. Silicone does not adhere to a damp surface.

Cleaning

- Before curing: Tools, surfaces and uncured residues can be removed with **Parasilico Cleaner, Multi-Purpose Super Cleaner** or **Paracleanex Wipes**.
- After curing: Remove cured sealant mechanically. Remainder of silicone can be removed with **Silicone Remover**.

Repairing

With the same product.

LIMITATIONS

- The sanitary formula does not replace cleaning of the joint. Strong pollution, caused by soap residues in combination with moisture, can stimulate the development of fungi.
- No adhesion on PE, PP, PTFE (Teflon®) and bituminous substrates.
- Do not use on natural stone (staining). Use **Parasilico NS (T)** or **Parasilico Prestige (T)** on natural stone.
- White or translucent colours can yellow slightly in the absence of UV light or through contact with smoke or detergents.
- Not compatible with the edge seals of insulating glazing and the PVB films of safety glass. Avoid direct contact.
- We recommend **Paracol Miroseal** for bonding mirrors.
- We recommend **Parasilico PL** on polyacrylate and polycarbonate.
- Not paintable.

TECHNICAL APPROVALS

FDA code 21 §177.2600 (e) (lanesco report No. 19-10734)

CE



CE
22 DL Chemicals
EN 15651-1 F EXT - INT EN 15651-2 G EN 15651-3 S No. DoP filled base: MP0020096 No. DoP trans- parent base: MP0020097



* Information sur le niveau d'émission de substances volatiles dans l'air intérieur, présentant un risque de toxicité par inhalation, sur une échelle de classe allant de A+ (très faibles émissions) à C (fortes émissions).

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply.